

## Product 511667



**511667 Passive holder with tilt swivel** Adjustable holder. Fits devices with slim skin.

Keep your iPhone 6 Plus in a passive holder on the road and you will always have it within easy sight and reach. Safe, comfortable and convenient! The holder has a neat and discreet design which blends well with the vehicle's interior. Your iPhone 6 Plus is held securely in place in an upright position for maximum cellular reception. You can connect an Apple Lightning cable and a headset to your iPhone 6 Plus while placed in the holder.

To use the holder, you first set the width to fit for your skin, then you can easily place your iPhone 6 Plus in the holder.

Fits devices with slim skins.

The holder is made of black ABS plastic. It is easy to put the device into the holder, and just as easy to take it with you when leaving the vehicle. The holder is equipped with a tilt swivel so you can adjust the angle of your device in order to avoid light reflection on the screen. Attach onto ProClip Mounting Platform.

EAN: 7320285116672

**Item no 511667 fits:**

Apple iPhone 6 Plus (For all countries)

## INSTALLATION INSTRUCTIONS



Please read all of the instructions and look at the pictures before attaching the holder.

1. To adjust the holder for your device: Loosen the screws on the front side of the holder, so the sides of the holders can be adjusted. Place the device in the holder and press the sides together so the device is firmly in place. Tighten the screws on the front side of the holder.

2. To install the holder: Loosen the screw in the center of the holder so you can remove the tilt swivel attaching plate on the back. Place the attaching plate onto the desired position. Screw the attaching plate into place with the enclosed screws.

3. Place the holder over the attaching plate so the screw fits in the hole in the tilt swivel. Screw a few turns on the screw, just so the thread starts to pull. Pull the holder toward you and hold it slightly tensed, in the same time tighten the screw so the holder is pulled toward the tilt swivel. Tighten the screw firm at first, then loosen it a bit so the holder is firmly in place, but still can be adjusted.

4. The holder is in place.